



CONCRETE SIDEWALK




## <u>DUMMY GROOVE</u> CONTRACTION JOINT




NOTE:
CONTRACTION JOINTS MUST BE SAWED AS SOON AS
CONCRETE HAS HARDENED SUFFICIENTLY TO PREVENT
DAMAGE TO FINISH FROM SAWING EQUIPMENT BUT IN
NO CASE LONGER THAN 16 HOURS AFTER INITIAL
PLACEMENT

SAWED CONTRACTION JOINT



DOWEL TYPE EXPANSION JOINT
IN CONCRETE PAVEMENT



©2016 Jones | Carter